



- (FR) Tore pour relais différentiels
- (GB) Torroid for HR relays
- (DE) Wandler für FI Relais
- (NO) Spole for jordfeilreleer HR
- (IT) Toro per rele HR
- (ES) Transformador diferencial
- (PT) Toro para rele HR

Notice d'instructions
User instructions
Bedienungsanleitung
Bruksanvisning
Istruzioni d'impiego
Instrucciones de uso
Instruções

HR741, HR742, HR743, HR744, HR745



